

ANARE Ski Lodge is a Non Smoking establishment.



Cooking with the Gas stove.

Note: if gas has been flowing for more than 10 seconds without lighting. Wait a few minutes for gas to disperse before attempting to relight.

Cook Top.

- Turn the burner knob to low,
- Light the gas with match or striker and then adjust to desired heat level.

Grill.

- Turn the grill knob to low,
- Push grill knob in to get gas to flow,
- Push the striker lever for spark to light gas or place striker or match under the grill burner until gas lights.

Oven (Fridge side).

Oven Knob



Striker Lever



Light with match



- Turn the Oven Knob to low,
- Push in Oven Knob to start gas flow,
- Open oven and push Striker Lever for spark to light gas or use a striker or long match to light burner.

ANARE Ski Lodge is a Non Smoking establishment.



Oven (Fire side).

Oven Knob



Striker Lever



Light with match



- Turn the Oven Knob to low,
- Open oven and pull and hold lever to get gas to flow,
- Use striker or long match to light burner.